

Dell Display and Peripheral Manager on Mac

User's Guide





NOTE: A NOTE indicates important information that helps you make better use of your computer.

Copyright © 2022 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

2022 - 09

Rev. A01

Contents

- Overview 5
- Downloading and setting up the Dell Display and Peripheral Manager. 6
 - Downloading Dell Display and Peripheral Manager 6
 - Connect your monitor and webcam to your Mac 6
- Before launching Dell Display and Peripheral Manager 7
- Using the Quick Settings dialog 8
- Launching Dell Display and Peripheral Manager . . 10
- Adjusting the brightness and contrast 11
- Setting the monitor display mode 12
- Organizing windows with Easy Arrange 13
- Using Application Window Snap 15
- Using the Webcam 16
 - Configuring Webcam 16
 - Webcam Control. 17
 - Color and Image 17
- Managing multiple video inputs 18
 - Selecting PIP/PBP mode 19
 - Setting up the KVM 20



Applying energy conservation features 23

Color Management 24

 Automatically adjust the default color profile in Mac
 when the color preset in monitor is changed 24

 Automatically change the color preset based on the
 change in the ICC profile 24

 Changing the ICC profile in Mac 25

Other shortcut keys 26

Restoring application positions 27

**Updating DDPM software, monitor and webcam
firmware 29**

 Updating DDPM software. 29

 Updating the monitor firmware 30

 Updating the webcam firmware 32

Improve DDPM 33

Troubleshooting 34

 Dell monitors and webcams not supported by
 Dell Display and Peripheral Manager 34

 Unable to detect supported Dell monitor or webcam . . . 34




Overview

Dell Display and Peripheral Manager (DDPM) is an Apple macOS application used to manage a monitor or a group of monitors or webcams.

Dell Display and Peripheral Manager allows manual adjustment of the displayed image, assignment of automatic settings, energy management, window organization, image rotation, and other features on selected Dell monitors and webcams.

After installing Dell Display and Peripheral Manager, it runs each time your system starts. A quick access icon is available in the status menu, with information about connected monitors available when you hover your cursor over the icon.



-  **NOTE: Some hardware-dependent features are only available on monitors or webcams that support those features. Refer to your monitors or webcams user guide for information about which features are available.**
-  **NOTE: Screenshots in this document are for illustrative purposes only. Some features may not be supported by your monitor or webcam.**



Downloading and setting up the Dell Display and Peripheral Manager

Downloading Dell Display and Peripheral Manager


Browse for your monitor or webcam model name, or type it in at <https://www.dell.com/support>. Download Dell Display and Peripheral Manager for Mac from the list of downloads, and install it on your Mac.

You can also visit <https://www.dell.com/support/ddpm> and download the software from the site. The Dell support website detects the OS of the device, and Dell Display and Peripheral Manager download link will appear if you are browsing from a Mac device.

Alternatively, Mac OS can be selected from the Operating System drop-down list.

Connect your monitor and webcam to your Mac

1. Connect your Mac to monitor or webcam as described in your monitor or webcam user guide.




- NOTE:** Connectivity diagrams are for illustrative purposes only. Refer to your monitor or webcam user guide for complete information about connecting your monitor.
- NOTE:** Ensure that the USB Type-C cable or USB upstream (USB Type-B) cable is connected between your Mac and your monitor or webcam.
- NOTE:** For Apple Silicon Mac, ensure that the USB upstream cable is connected between your Mac and your monitor.




Before launching Dell Display and Peripheral Manager

Before launching Dell Display and Peripheral Manager, go to **Others** in your monitor's On-Screen Display menu and ensure that the **DDC/CI** feature is enabled.



When launching Dell Display and Peripheral Manager for the first time, the application will request access to **Screen Recording and Accessibility** privileges on your Mac.

Click **Open System Preferences** and follow the on-screen instructions to enable **Screen Recording** and **Accessibility**.



 **NOTE: Screen Recording and Accessibility privileges must be granted in order for Dell Display and Peripheral Manager to launch on your Mac.**




Using the Quick Settings dialog

Clicking Dell Display and Peripheral Manager icon on the status bar opens the **Quick Settings** dialog box. When multiple Dell monitors are connected to the computer, you can select any monitor from the drop-down menu.

The **Quick Settings** dialog box provides quick access to commonly-used features, such as configuring the monitor:

- **Resolution**
- **Brightness** and **Contrast**
- Presets (auto or manual mode)

A list of recently-used layouts are available for quick selection. Click on the **More Options** to access other layouts from the **Easy Arrange** menu in the Dell Display and Peripheral Manager interface.



 **NOTE:** Dell Display and Peripheral Manager matches customized System Preferences applied on your Mac.




Feature	Function	Description
Quick DDPM Access	Shortcut key to launch Quick Settings dialog box	• Ctrl+Shift+D
	Select monitor when multiple monitors are connected	• When more than one monitors are connected to the computer, select the monitor from the model drop-down list to configure the monitor. • When the monitor is selected from the UI, the selected monitor screen will be dimmed momentarily, showing a monitor icon with the model name on the screen to indicate the physical screen selected. • Press Ctrl + Shift + D to bring up the Quick Settings dialog box of the monitor where the mouse pointer is currently located.
	Select webcam when more than one webcams are connected	• When more than one webcams are connected to the computer, select the webcam from the model drop-down list to configure the webcam. • When the webcam is selected from the UI, the webcam preview window will be OFF momentarily, showing a webcam icon with the model name on the screen to indicate the webcam selected. Press Ctrl + Shift + D to bring up the Quick Settings dialog box of the webcam where the mouse pointer is currently located.




Launching Dell Display and Peripheral Manager

Launch the Dell Display and Peripheral Manager by one of the following methods:

- Right-click on the DDPM icon on the status bar and select **Open Dell Display and Peripheral Manager...**



- Click DDPM icon from the **Quick Settings** Dialog box.




Adjusting the brightness and contrast


In Dell Display and Peripheral Manager menu, access the **Brightness/Contrast** menu to change the brightness and contrast levels.

Feature	Function	Description
Brightness/ Contrast	Brightness / Contrast	Adjust the monitor brightness and contrast.
	Enable display matrix control	Enable this feature to allow you to apply the brightness, contrast and color presets controls to all connected supported monitors.

 **NOTE: “Enable display matrix control” is active when multiple monitors are connected**



Single monitor connection user interface



Multi-monitor connection - Enable display matrix control




Setting the monitor display mode

The **Color** menu allows you to associate any **Preset Mode** with an application. When **Auto Mode** is enabled, Dell Display and Peripheral Manager automatically switches to the corresponding **Preset Mode** whenever the associated application is activated. The **Preset Mode** assigned to a particular application may be the same on each connected monitor, or it can vary from one monitor to another.

To add a new application to the assignment list, go to finder to search for the application, drag it from the Finder and drop to the current list. Choose the preset from the **Preset Mode** drop-down list to associate the preset to the application.

Feature	Function	Description
Color	Resolution	Change screen resolution.
	Auto Mode	- Click on the Configure button to access the Auto Mode menu to assign a preset mode to an application. - Enable this feature to activate the preset mode automatically when the associated application is selected as the active window.
	Manual Mode	Select the preset mode manually from the user interface.

 **NOTE: Preset Mode assignments for batch files, scripts, shortcuts, and non-executable files such as zip archives or packed files, are not supported.**




Organizing windows with Easy Arrange

The **Easy Arrange** menu simplifies the applications window organization on the monitor. To use it:

1. Select any of the predefined layout to virtually divide the screen into multiple zones.
2. Drag the application to your selected zone to position the application in the zone. The application will snap to the selected zone.

Click the > icon to explore more layouts. To create a custom layout, arrange the application zone positioning by resizing the zone for the opened windows and then click **Save** to save the layout as custom layout.



Feature	Function	Description
Easy Arrange	Overlap transparent borders	Enable the feature to allow application snap side by side without gap.
	Hold down the SHIFT key to enable zone positioning	Enable the feature to require you to press the Shift key to activate the Easy Arrange positioning.
	Application Window Snap	Quick access to snap application window to recently-used layout.
	Span multiple monitors	If you are using multiple monitors in an array or matrix, the Easy Arrange layout can be applied across all the monitors as one desktop. You need to align your monitors properly to make it effective.
Enhanced Easy Arrange	Custom layouts	- Save and name five customized Easy Arrange patterns. - Configure x*y patterns.
	Recently-used layouts	Press Ctrl+Shift+7 to cycle among recently-used layouts.
	On-the-fly partition resizing	- Move the mouse cursor to the layout pattern, right-click the mouse and select Customize Layout. - Press and hold mouse left button to move border. The new layout will be saved after five seconds when the mouse left button is released.
	Easy Arrange layouts for portrait mode	Portrait mode Easy Arrange icons are presented when monitor is rotated.

 **NOTE: If an application window cannot fit in the zone defined by Easy Arrange, the application may not display properly.**

 **NOTE: Disable the Mac “Display have separate spaces” before using the Easy Arrange function.**




Using Application Window Snap

The **Application Window Snap** is designed to enable application placement on any screen quickly. When this function is enabled in Dell Display and Peripheral Manager, dragging the application triggers a floating menu that contains recently-used **Easy Arrange** layouts. Drop the application to any one of the listed layouts to perform window placement.


When this function is turned on, it replaces the Easy Arrange option such that user can snap their application conveniently to the respective monitor and zone in the latest three recently used Easy Arrange layout.

You can enable this feature by one of the following methods:

- Launch Dell Display and Peripheral Manager, go to **Easy Arrange** menu, and select **Application Window Snap** to enable the function.




- Right-click on the DDPM icon on the status bar, and select **Application Window Snap** to enable the function.



Using the Webcam


Configuring Webcam

Feature	Function	Description
Camera selection and preview	Camera selection	Select the connected cameras.
	Preview window	View camera images in real time.
	Zoom	Zoom in and zoom out camera preview.
Webcam Control	Camera Preset	You can select a preset that suits your style depending on how you want the image to appear on the camera from the options provided. You can also create a custom preset.
	AI Auto Framing	Always stay focused. The AI Auto Framing keeps you at the center of the picture no matter where you move.
	Field of View	You can set the viewing angle by adjusting your field of view to 65°, 78° or 90° if available.
Microphone	Camera Microphone	- You can switch on or off the built-in microphone for clear communication optimized for personal workspace. NOTE: Camera Microphone is available on the following model: - Webcam: WB5023




Webcam Control

You can adjust **AI Auto Framing**, **Field of View**, **Zoom**, **Autofocus**, **Priority**, and Camera switch from the **Webcam Control** section of the user interface.



Color and Image

It is possible to adjust the automatic correction for optimal image quality at various lighting conditions using **HDR** (High Dynamic Range). Other settings like **Auto White Balance**, **Brightness**, **Sharpness**, **Contrast**, **Saturation**, and **Anti Flicker** for the Dell Webcam makes it easier to get an image of your choice. The user interface is simple and intuitive to achieve this.



 **NOTE:** AI Auto Framing and HDR features are available on all supported Dell Displays and Dell Webcams connecting to the Mac using any type of USB cable except for the following models that must be connected to the Mac using the USB 3.0 cable:


- Webcam: WB7022



Managing multiple video inputs


The **Input Source** menu provides convenient ways for you to manage multiple video inputs connected to your Dell monitor. This makes it easy to switch between inputs while you work with multiple computers.

All video input ports available to your monitor are listed. You can assign each input with a name. Save your changes after editing.




 **NOTE: Refer to your monitor user guide for available inputs.**

Assign shortcut keys for quick access to your favorite input and switch between two inputs. Alternatively, switch the input source from the menu drop-down list.




Selecting PIP/PBP mode

1. Click on the **PIP/PBP mode...** (Picture-in-Picture/Picture-by-Picture) icon to enable the split screen function on supported models.




2. Select a target window size to split the screen to suit your need.




Setting up the KVM

For monitors that supports KVM feature, click on the **KVM wizard** icon and follow the on-screen wizard flow to set up the devices connecting to the monitor.






The on-screen wizard flow is illustrated in the following screenshots.

- 1. Select the number of sources your monitor is connected to.




- 2. Pair the input sources with USB connections and assign preferred names.






3. Select a preferred partition.



4. Click **Finish** to save and exit **KVM wizard**.




 **NOTE:** Dell Display and Peripheral Manager communicates with your monitor even when the monitor is displaying video from another computer. You can install Dell Display and Peripheral Manager on the computer you frequently use and control input switching from it. You may also install Dell Display and Peripheral Manager on other computers connected to the monitor.



Applying energy conservation features


On supported Dell models, PowerNap energy conservation options are available in **Others** menu. You can choose to set the brightness of the monitor to the minimum level, or to put the monitor to sleep when the screen saver is activated.



Color Management

This feature provides the optimum color experience by matching the color space of the monitor with the International Color Consortium (ICC) profile.

On the supported Dell models, **Color Management** options are available under **Others** menu. You can choose **Automatically adjust the default color profile in Mac when the color preset in monitor is changed** or **Automatically change the color preset based on the change in the ICC profile**.



Automatically adjust the default color profile in Mac when the color preset in monitor is changed

The corresponding color profile will set to default in Mac when you change the color preset from the monitor OSD menu.


Automatically change the color preset based on the change in the ICC profile

The corresponding color preset will be set in the monitor when you change the ICC profile in Mac. You can click on the ICC profile link to add the color profile installed for the monitor.




Changing the ICC profile in Mac

1. Open the **ColorSync Utility** app in Mac. Find the current display, click on **Current Profiles** drop-down list, and select **Other...**.



2. Select the profile (.icm file) you wish to apply.




3. DDPM will apply the corresponding color preset to your monitor OSD.



Other shortcut keys

Assign shortcut keys for quick access to commonly-used features.




Feature	Function	Description
Shortcut Keys	Program shortcut key	Quick access to open the Quick Settings dialog box.
	Easy Arrange MRU shortcut key	Cycle through the 6 recently-used window layouts.
	PIP position shortcut key	Quick access to apply the PIP sub position of the window position to Top-Left, Top-Right, Bottom-Right or Bottom-left.
	Application Window Snap shortcut key	Quick access to snap application window to recently-used layout.




Restoring application positions


Dell Display and Peripheral Manager can help you restore application windows into their positions when you reconnect your PC to the monitor(s). Access this feature by right-clicking on Dell Display and Peripheral Manager icon in the notification tray.



If you choose **Auto-restore window layout**, your application windows positions are tracked and remembered by Dell Display and Peripheral Manager. Dell Display and Peripheral Manager automatically places the application windows into their original positions when you reconnect your PC to your monitor(s).



To go back to a favorite layout, first select **Save current window layout** and then **Restore saved window layout**.



You may use monitors with different models or resolutions in your daily routine, and you may apply different window layouts on them. Dell Display and Peripheral Manager registers the monitor you have reconnected and restore application positions accordingly.

In case you need to replace a monitor in a monitor matrix configuration, you can save the window layout before replacement and restore the layout after a new monitor is connected.

 **NOTE: You should keep your applications running in order to benefit from this feature. Dell Display and Peripheral Manager does not launch applications.**




Updating DDPM software, monitor and webcam firmware


If your computer is connected to the Internet, you will be prompted to upgrade to a newer version of DDPM software, monitor firmware or webcam firmware when the updated version is available. It is recommended to download and install the latest DDPM application, and monitor or webcam firmware.

Updating DDPM software

You can check for new DDPM version by right clicking on Dell Display and Peripheral Manager icon.




Click **Update** in **Settings** to update the DDPM software or device firmware.
You can also check for new version by clicking on **Check for Updates** in **Settings**.




Updating the monitor firmware


- 1. Click **Update** to download the pkg file. After download is complete, a dialog box appears to prompt for confirmation. Follow on-screen instruction to disconnect all other monitors before clicking **Yes**.



- 2. The **DDPM** will close, and **Monitor Firmware Updater Utility** will appear after you confirm to update firmware. Click **Update** to start firmware update.





3. After the update is complete, click **Close** to exit **Monitor Firmware Updater Utility** and reboot the monitor.




Updating the webcam firmware

Webcam firmware version can be found in **Help** dialog. Webcam firmware can be upgraded in **Settings** dialog. You can click **Update** to download and update Dell Webcam firmware immediately.




Improve DDPM

Check the **Help Dell improve its product and services automatically** if you consent to provide diagnostic and usage data to Dell server automatically. This data will help to improve Dell products and services.




Troubleshooting

If Dell Display and Peripheral Manager does not work with your monitor or webcam, it will display the following icon and message in the status menu.



Click on the icon, Dell Display and Peripheral Manager shows a more detailed error message.



Please note that Dell Display and Peripheral Manager only works with selected Dell-branded monitors or webcams. If you are using monitors or webcams from other manufacturers, Dell Display and Peripheral Manager does not support them.

Dell monitors and webcams not supported by Dell Display and Peripheral Manager

Dell Display and Peripheral Manager may not work with the following monitors or webcams:

- Dell monitor or webcam models not included in Dell Display and Peripheral Manager for Mac supported list. For more information, see <https://www.dell.com/support/ddpm>
- Monitors, webcams and accessories not listed in Dell Display and Peripheral Manager for Mac support list. Virtual and wireless monitors do not support DDC/CI
- Mac models earlier than year 2018
- macOS earlier than 10.14

Unable to detect supported Dell monitor or webcam

If Dell Display and Peripheral Manager is unable to detect and/or communicate with a supported Dell monitor or webcam, please take following actions to troubleshoot:

1. Make sure the video cable or USB upstream cable is properly connected to your monitor or webcam and your computer. Ensure all the connectors are firmly inserted into the ports.



2. If connecting HDMI cable not working, switch to use HDMI and USB upstream cable. Launch DDPM again.
3. Check the monitor OSD to ensure **DDC/CI** is enabled.
4. Remove any docking stations or cable extenders or converters between the monitor and the graphics port. Some low-cost extenders, hubs or converters may not support DDC/CI properly and can fail Dell Display and Peripheral Manager. Update the driver of such device if the latest version is available.
5. Check if the webcam is detected under USB section in System Information
6. Wait for a few seconds after unplugging the webcam before re-connecting it to the computer.
7. Restart your system.

